



2014

**Forklift Service Training:
35-50 Diesel -9A**

Introduction Hyundai's production plant (Ulsan)



Table of content

- A. General machine introduction.**
- B. Transmission.**
- C. Brake systems.**
- D. Hydraulics.**
- E. Electric.**
- F. Engines.**
 - 1. After treatment device**
 - 2. DST-i tool**
- G. Maintenance.**

35D / 40D / 45D / 50DA – 9A Introduction




- Engine: Kubota V3800-CR-TE4
- Rated Power: 61.0Kw / 2200 rpm.
- Max Torque: 335.5 Nm / 1500 rpm
- Noise level Lpa: 82.6/83.7 dBA
- Noise level Lwa: 106.4 dBA
- Vibration level: 0.401 m/s²
- Speed: +/- 27 km/h
- Fuel consumption acc. 60 VDI: 5.5l (45D-9A)




45D-9A fuel consumption.pdf

35D / 40D / 45D / 50DA – 9A Component location

- 1 Mast
- 2 Lift cylinder
- 3 Steering unit
- 4 Tilt cylinder
- 5 Control valve
- 6 Fork
- 7 Front wheel
- 8 Drive axle
- 9 Hydraulic pump
- 10 Transmission
- 11 Torque converter
- 12 Engine
- 13 Exhaust pipe
- 14 Air cleaner
- 15 Steering axle
- 16 Steering cylinder
- 17 Rear wheel
- 18 Radiator
- 19 Muffler
- 20 Silencer
- 21 Overhead guard
- 22 Seat
- 23 Control lever
- 24 Steering wheel
- 25 Drive shaft




Torque Converter; Transmission; Front axle/differential




Torque Converter – basic data

Item		Unit	Specification	
Torque converter	Type	-	3 elements 2 phase 1 stage	
	Power transmit	-	Torque converter	
Transmission	Type/Gear shift	-	POWER SHIFT / F2 : R2	
	Gear ratio	FR/RR 1 stage	-	2.550
		FR/RR 2 stage	-	1.218
	P.T.O system	-	Included	
	T/M oil	-	DEXRON 3	
Oil quantity	l	12		
T/M valve	Type	-	Electric	
Charging pump	Displacement	cc/rev	20.6	
Drive axle	Gear ratio	Differential	-	2.923
		Planetary	-	4
		Total	-	11.692
	Axle oil	-	MOBILFLUID 424 + Shell Donax TD(10W30)	
	Oil quantity	l	10.5	
Brake	Service brake	-	Wet disk brake	
	Brake oil	-	AZOLLA-ZS32	
	Parking brake	-	Seperated drum brake	
Differential	Gear type	-	Spiral bevel gear	
	Differential type	-	4 pinions	



No	Item	Specification
1	Torque converter input plate	4.5 ± 0.3 kg·m (32.5 ± 2.2 lbf·ft)
2	Torque converter pump gear	2.0 ± 0.3 kg·m (14.5 ± 2.2 lbf·ft)
A	Pilot boss outer diameter	19.959 - 19.980 mm (0.786 - 0.787 in)
B	Oil seal outer diameter	134.9 - 135.0 mm (5.311 - 5.315 in)
C	Needle bearing outer diameter	68.000 - 68.019 mm (2.677 - 2.678 in)
D	Seal ring inner diameter	60.333 - 60.363 mm (2.375 - 2.376 in)



Torque Converter - troubleshooting



Engine rpm	Unit	Main line (Neutral)	T/C input port (Neutral)	T/C output port (Neutral)	FR 1,2 stage clutch	RR 1,2 stage clutch
Idle	kgf/cm ² (psi)	6.5~13.2 (92.5~187.7)	0.7~4.2 (9.9~59.7)	0.2~1.2 (2.8~17.1)	6.5~13.2 (92.5~187.7)	6.5~13.2 (92.5~187.7)
1300	kgf/cm ² (psi)	7.5~14.5 (106.7~206.2)	1.5~9.1 (21.3~129.4)	0.7~2.5 (10.0~35.6)	7.5~14.5 (106.7~206.2)	7.5~14.5 (106.7~206.2)
2200	kgf/cm ² (psi)	7.5~15.0 (106.7~213.4)	2.6~11.1 (37.0~157.9)	1.0~4.2 (14.2~59.7)	7.5~15.0 (106.7~213.4)	7.5~15.0 (106.7~213.4)



Model	Engine Max	T/C Stall	Hyd. Stall	Full Stall
35/40/45D-9A, 50DA-9A	2450	1770	2300	1200

Signal	Value	Unit
Final Fuel Injection Quantity	76.54	mm ³ /st
Engine Speed	1764	/min(rpm)
Coolant Temperature	77	°C
Differential Pressure 1	3.22	kPa
Exhaust Gas Temperature 0	245	°C
Exhaust Gas Temperature 1	229	°C
Exhaust Gas Temperature 2	161	°C
PM Sedimentation Quantity 1	4000	mg
PM Sedimentation Quantity 2	13262	mg
Fuel Quantity after Regeneration	12	L
DPF Regeneration Last Active Time	38.80	h



Detailed procedure can be found in Service Manual

Transmission – basic data




- 1 Torque converter
- 2 Input shaft
- 3 3 P.T.O gears
- 4 Pump assembly
- 5 Gear (RR, 2 stage)
- 6 Clutch (RR, 2 stage)
- 7 Clutch drum (RR)
- 8 Clutch piston
- 9 Valve assembly
- 10 Clutch (RR, 1 stage)
- 11 Gear (RR, 1 stage)
- 12 Gear (FR, 1 stage)
- 13 Clutch (FR, 1 stage)
- 14 Gear (Output, 1 stage)
- 15 Output shaft
- 16 Clutch drum (FR)
- 17 Clutch (FR, 2 stage)
- 18 Gear (Output, 2 stage)
- 19 Gear (FR, 2 stage)
- 20 Counter shaft

- 1 Cylinder clutch (RR)
- 2 Gear (RR, 2nd stage)
- 3 Gear (RR, 1st stage)
- 4 Gear (Output, 1st stage)
- 5 Gear (Output, 2nd stage)
- 6 Gear (FR, 1st stage)
- 7 Gear (FR, 2nd stage)
- 8 Gear clutch (FR)

※ Selection of either forward or reverse gear makes all of the parts inside the T/M operate.

Transmission - troubleshooting




Direction solenoid data

Engine rpm	Unit	Main line (Neutral)	T/C input port (Neutral)	T/C output port (Neutral)	FR 1,2 stage clutch	RR 1,2 stage clutch
Idle	kgf/cm ² (psi)	6.5~13.2 (92.5~187.7)	0.7~4.2 (9.9~59.7)	0.2~1.2 (2.8~17.1)	6.5~13.2 (92.5~187.7)	6.5~13.2 (92.5~187.7)
1300	kgf/cm ² (psi)	7.5~14.5 (106.7~206.2)	1.5~9.1 (21.3~129.4)	0.7~2.5 (10.0~35.6)	7.5~14.5 (106.7~206.2)	7.5~14.5 (106.7~206.2)
2200	kgf/cm ² (psi)	7.5~15.0 (106.7~213.4)	2.6~11.1 (37.0~157.9)	1.0~4.2 (14.2~59.7)	7.5~15.0 (106.7~213.4)	7.5~15.0 (106.7~213.4)


Item	Unit	Specification
Initial coil current at 20°C	A / VDC	0.7/24
Resistance at 20°C	Ω	39.3
Shifting time	sec	1.0 ~ 1.6
Connector	-	DR/D Models With Diode

Item	Unit	Specification
Rated flow	ℓ /rpm	37.4 / 2200
Main relief pressure	kgf/cm ² (psi)	7.0 ~ 15.0 (99.6~213.4)
T/C relief pressure	kgf/cm ² (psi)	0.8 ~ 7.2 (11.4~102.4)
Clutch pressure	kgf/cm ² (psi)	7.0 ~ 15.0 (99.6~213.4)
Residual pressure (Clutch release condition)	kgf/cm ² (psi)	Max. 0.3(4.3)




Detailed procedure can be found in Service Manual

Transmission - troubleshooting




Engine rpm	Unit	Main line (Neutral)	T/C input port (Neutral)	T/C output port (Neutral)	FR 1,2 stage clutch	RR 1,2 stage clutch
Idle	kgf/cm ² (psi)	6.5~13.2 (92.5~187.7)	0.7~4.2 (9.9~59.7)	0.2~1.2 (2.8~17.1)	6.5~13.2 (92.5~187.7)	6.5~13.2 (92.5~187.7)
1300	kgf/cm ² (psi)	7.5~14.5 (106.7~206.2)	1.5~9.1 (21.3~129.4)	0.7~2.5 (10.0~35.6)	7.5~14.5 (106.7~206.2)	7.5~14.5 (106.7~206.2)
2200	kgf/cm ² (psi)	7.5~15.0 (106.7~213.4)	2.6~11.1 (37.0~157.9)	1.0~4.2 (14.2~59.7)	7.5~15.0 (106.7~213.4)	7.5~15.0 (106.7~213.4)




Detailed procedure can be found in Service Manual

Front axle – outlook




- 1 Sun gear
- 2 Planetary gear
- 3 Inner gear
- 4 Inner gear carrier
- 5 Tapered bearing
- 6 Hub assy
- 7 Disk brake


- 8 Drive shaft
- 9 Differential carrier assy
- 10 Ring gear
- 11 Pinion shaft
- 12 Spider
- 13 Differential pinion gear
- 14 Differential side gear



Differential – structure



No	Item	Unit	Specification
1	Differential pinion gear inner diameter	mm (in)	20.000 - 20.021 (0.787~0.788)
2	Spider outer diameter	mm (in)	19.959 - 19.980 (0.786~0.787)
3	Pinion gear washer	mm (in)	1.92 - 2.08 (0.076~0.082)
4	Side gear washer	mm (in)	1.95 - 2.05 (0.077~0.081)
5	Side gear	-	-



Differential – adjustment

ADJUSTMENT OF BEVEL PINION SHAFT

Adjusting shim of bevel pinion shaft.

Adjust shim thickness and bevel pinion shaft with following method.

- ① Measure "E" at the housing.
- ② By the equation " $X = E - B - T \pm C$ ", define the the shim thickness(1).

B : Mounting dimension of bevel pinion shaft , 133.20mm (5.2 in)

T : Height of bearing.

C : Dimension of carved seal on the pinion. If there's no carved seal C=0.

EX) : From the housing

"E" = 162.85 mm

B is factory dimension

"B" = 131.20 mm

From the bearing

"T" = 31.5 mm


Mark on the pinion

"C" = 0.05 mm

Shim thickness :

$$\begin{aligned} "X" &= 162.85 - 131.20 - 31.5 - 0.05 \\ &= 0.10 \text{ mm} \end{aligned}$$

- ※ If teeth are damaged, replace it as a set (Bevel gear and shaft). Do not reuse damaged shims and bearing.



Install differential assembly into the carrier.

Place the bearing cup and screw into the housing.

At that moment, using a screw adjust rotation backlash.

Install the dial gauge on the gear tooth and measure the backlash while rotating bevel gear.

- ※ Rotation backlash : 0.18~0.23 mm

Assemble bearing cap.

- ※ Fix bearing cap with hexagon bolt.
 - Tightening torque : 15~17 kg·m

Measure rolling resistance of tapered roller bearing.

The following table shows the relation between preload (P) of bevel pinion shaft and rolling resistance (Z).

(Calculated at ADJUSTMENT OF PINION SHAFT ②)




Unit : kgf·m

P	Z
0.20 (1.45)	0.44~0.47
0.25 (1.81)	0.49~0.52
0.30 (2.17)	0.55~0.58
0.35 (2.53)	0.59~0.62







Brake systems and final drive



Brake systems – structure / adjustment (including inching linkage)

DISK BRAKE


Item	Specification	
Type	Wet disk brake	
Brake valve step/bore piston diameter	40 mm (1.6 in) / 30 mm (1.2 in)	
Pedal adjustment	Pedal height	131-139 mm (5.16-5.47 in)
	Play	2-4 mm (0.08-0.16 in)
Brake oil	Azolla ZS32 (ISO VG32 hydraulic oil)	





PARKING BRAKE

Item	Specification
Type	Ratchet, internal expanding mechanical type
Parking lever stroke	23°
Parking cable stroke	28 mm (1.1 in)


Brake systems – structure / adjustment (new longer inching link)



1. Adjust brake pedal play to 3 mm




2. Adjust market gap to 0 mm



89FV-40822	#0028 -	B	35D-9A
89FV-40821	- #0021		40D-9A
89FV-40822	#0022 -	B	40D-9A
89FV-40821	- #0066		45D-9A
89FV-40822	#0067 -	B	45D-9A
89FV-40821	- #0059		50DA-9A
89FV-40822	#0060 -	B	50DA-9A



3. Check T/M pressure whether is "0" bar when inching pedal fully pressed and brake pressure if it is max 3 bar @ drive off.



4. Adjust inching pedal free play – 5 mm by cable.


5. After brake pedal releasing, brake pressure should be "0".

Brake systems – structure of brake valve




- | | | |
|-----------------|------------------|------------------|
| 1 Front housing | 11 U-cup seal | 21 O-ring |
| 2 Rear housing | 12 U-cup seal | 22 Spring |
| 3 Push rod | 13 U-cup seal | 23 Gauge |
| 4 Bellows | 14 U-cup seal | 24 Air bent |
| 5 Master piston | 15 Relief piston | 25 Plug |
| 6 Lock washer | 16 Relief spring | 26 O-ring |
| 7 Piston ball | 17 Relief plug | 27 Bolt |
| 8 Piston ring | 18 O-ring | 28 Spring washer |
| 9 Servo piston | 19 O-ring | |
| 10 Servo spring | 20 Ball | |



Brake systems – structure of wheel brake



Disc must be assembled
after the oil immersion
during 12 hours
(MOBILFLUID #424)




After assembling, confirm that
the clearance between the outer
plate and the axle housing
surface is 2.1~2.6 mm



Detailed procedure can be found in Service Manual

Brake systems – structure of wheel brake




- **Condition that brake discs become worn out.**

Then, the distance between disc plate and piston will be increased, which will also request piston to travel more for brake activation.

But, before piston moves to left more, travel distance for bushing is quite limited and will soon stopped.

In this stage, piston will be slipped on bushing in order to move left more for brake activation thanks to brake oil pressure




Brake systems – structure of parking brake and adjustment

The following procedures should be applied for brake shoe adjustment

Open rubber plug on brake drum.


Adjuster should be turned according to arrow direction until occurring drum touch condition.

Adjuster should be turned to opposite direction of the arrow sign by four click.


At that case, lining clearance is 0.1~0.25 mm. 

Check drum drag after operating lever several times.


(Repeat from beginning if drag is occurred)




- 13 lock nut
- 14 yoke
- 15 bolts
- 16 parking brake
- 17 pinion shaft




Final drive – structure




o-ring (2)
snap ring (3)







planet gears (5)
needle bearings (6)
thrust washers (7)



bolt (11)
plate assembly (12)
ring gear (13)
c-ring (14)
spindle (15)



gear (8)
drive shaft (9)
snap ring (10)





Necessary to measure the rolling resistance of tapered roller bearing before disassembly (value needed for reassembly later)

Detailed procedure can be found in Service Manual

Hydraulic system




Hydraulic system – diagram





- 1 Hydraulic gear pump
- 2 Main control valve
- 3 Steering unit
- 4 Priority valve
- 5 Brake valve
- 6 Check valve
- 7 Steering cylinder
- 8 Tilt cylinder
- 9 Lift cylinder
- 10 Suction filter
- 11 Return filter
- 12 Down safety valve
- 13 Down control valve
- 14 DPF solenoid valve
- 15 Flow control valve ?
- 16 Hydraulic oil tank

Model	Main	Aux	Steering	DPF valve	Brake boost
35D-9A	175 +5/-0	150 +5/-0	135 +5/-0	55 ±3	45±2
40D-9A	195 +5/-0	150 +5/-0	135 +5/-0	55 ±3	45±2
45D-9A	210 +5/-0	150 +5/-0	135 +5/-0	55 ±3	45±2
50DA-9A	210 +5/-0	150 +5/-0	135 +5/-0	55 ±3	45±2

Hydraulic system – Pump and priority valve improvement




Description	Old	New
	Round head plug	Hex head plug
Picture		
Part No.	31HP-03010	←
Information	Control pressure of LS-spool change (7 → 10 kgf/cm ²)	
Remark	LS-spool repair kit (XKAU-00546) 	




Item	Unit	Specification
Type	-	Fixed displacement gear pump
Capacity	cc/rev	50
Maximum operating pressure	bar	250
Rated speed (Max/Min)	rpm	3000/600

Hydraulic system – MCV



Model	Main	Aux	Steering	DPF valve	Brake boost
35D-9A	175 +5/-0	150 +5/-0	135 +5/-0	55 ±3	45±2
40D-9A	195 +5/-0	150 +5/-0	135 +5/-0	55 ±3	45±2
45D-9A	210 +5/-0	150 +5/-0	135 +5/-0	55 ±3	45±2
50DA-9A	210 +5/-0	150 +5/-0	135 +5/-0	55 ±3	45±2






To set pressure for DPF valve machine should be either in DPF level 1 or 2, or valve must be powered (24V) externally.



Port name	Size	Item	Unit	Specification
Inlet port	1-5/16-12UN	Type	-	Sectional
Outlet port	1-5/16-12UN	Operating method	-	Mechanical
Gauge port	PF1/4	Main relief valve pressure	bar	210/150
3 Work port	1-1/16-12UN	Flow capacity	lpm	125



Hydraulic system – MCV




- 2 Main relief valve
- 7 Inlet section assy
- 8 Spool section-lift
- 9 Spool section-tilt
- 10 Spool section-A1
- 11 Spool section-A2
- 12 Outlet section assy
- 13 O-ring

- 16 Screw
- 17 Seal plate
- 18 Wiper
- 19 Spool seal
- 20 Spool cap
- 21 Screw cap
- 22 Screw cap
- 23 Spool end

- 25 Spring seat
- 27 Spring
- 28 Spring
- 29 Piston
- 30 Spool end
- 31 Spool end
- 32 Spool cap




Hydraulic system – Steering (incl. axle structure)




- 1 Axle center
- 2 Knuckle-RH
- 3 Knuckle-LH
- 4 King pin
- 5 Taper roller bearing
- 6 Hexagon bolt
- 7 Spring washer
- 8 Special bolt
- 9 Spring washer
- 10 Grease nipple
- 11 Collar
- 12 Oil seal
- 13 Retaining ring
- 14 Hub
- 15 Oil seal
- 16 Taper roller bearing
- 17 Taper roller bearing
- 18 Slotted nut
- 19 Split pin
- 20 Hub cap
- 21 Serration bolt
- 22 Link-RH

- 23 Link-LH
- 24 SPH plain bearing




- 25 Thrust washer
- 26 Clevis pin
- 27 Plain washer
- 28 Split pin
- 29 Steering cylinder
- 30 Pin
- 31 Lock plate
- 32 Hexagon bolt
- 33 Support
- 34 Bushing
- 35 Grease nipple
- 36 Hexagon bolt
- 37 Spring washer
- 38 Upper cover
- 39 Lower cover
- 40 Shim (0.1t)
- 41 Shim (0.15t)
- 42 Shim (0.3t)
- 43 Retaining ring
- 44 Shim (0.5t)
- 45 Hub nut
- 51 Hexagon bolt
- 52 Spring washer

Model	Steering
35D-9A	135 +5/-0
40D-9A	135 +5/-0
45D-9A	135 +5/-0
50DA-9A	135 +5/-0




Hydraulic system – Steering (incl. axle structure)




- Min. turning radius:
- 35D-9A - 2868 mm (113 in)
 - 40D-9A - 2915 mm (115 in)
 - 45D-9A - 2965 mm (117 in)
 - 50DA-9A - 3004 mm (118 in)

Type	Unit	Center pin support single shaft
Structure of knuckle	-	Elliott type
Toe-in	degree	0
Camber	degree	0
Caster	degree	0
King pin angle	degree	0
Max steering angle of wheels(Inside/Outside)	degree	74.8/53.8
Tread	mm (in)	1140 (45)

Electric system



Electric system – electric diagram





35-50D-9A part 01.pdf


35-50D-9A part 02.pdf



35_50D-9A knob FR switch.pdf

Electric system – components location





- 1 Work lamp
- 2 Battery
- 3 Master switch
- 4 Start relay
- 5 Fuel sender
- 6 Mast angle sensor*
- 7 High horn
- 8 Back buzzer
- 9 Licence plate lamp
- 10 Beacon lamp
- 11 Forward-reverse lever
- 12 Cluster
- 13 Head lamp switch
- Illumination lamp
- Turn signal switch
- 14 Horn button
- 16 Brake oil switch
- 17 Work lamp switch (opt)
- 19 Parking lever

*Only mast angle indicator available, no option for auto-tilt



Electric system – tip




To avoid potential problems with gear shifting, please double re-check all ground connections to the machine frame





Electric system – tip



To avoid potential problems with gear shifting, please double re-check all ground connections to the machine frame





Electric system – sensors' location, examples



Electric system – sensors' location, examples



CD-4		N30 AWG20
PS OUTPUT	<input type="radio"/> 4	
SWITCH	<input type="radio"/> 3	N19 AWG20
POWER(8-32V)	<input type="radio"/> 2	130 AWG20
RETURN	<input type="radio"/> 1	G3 AWG20

BRAKE PS SENSOR




CD-29		POWER(8-30V)
<input type="radio"/> 2		
<input type="radio"/> 3		TEMP OUTPUT
<input type="radio"/> 4		PS OUTPUT
<input type="radio"/> 1		RETURN

T/M PS/TEMP SENSOR



Electric system – components' location, examples





Internal G-sensor

CH636NN CONNECTOR	
GROUND	34
RES232 (K10V HMI)	33
RELAY-BRAKE LAMP	32
SENSOR-BRAKE OIL PS	31
SENSOR-OIL OIL PS	30
SENSOR-OIL OIL TEMP	29
SENSOR-OIL OIL TEMP	28
SENSOR-OIL OIL TEMP	27
ANALOG-IN (V)	26
DIETAL-IN (GND)	25
DIETAL-IN (GND)	24
DIETAL-IN (POWER)	23
DIETAL-IN (GND)	22
DIETAL-IN (GND)	21
DIETAL-IN (GND)	20
DIETAL-IN (GND)	19
DIETAL-IN (GND)	18
DIETAL-IN (GND)	17
DIETAL-IN (GND)	16
DIETAL-IN (GND)	15
DIETAL-IN (GND)	14
DIETAL-IN (GND)	13
DIETAL-IN (GND)	12
DIETAL-IN (GND)	11
DIETAL-IN (GND)	10
DIETAL-IN (GND)	9
DIETAL-IN (GND)	8
DIETAL-IN (GND)	7
DIETAL-IN (GND)	6
DIETAL-IN (GND)	5
DIETAL-IN (GND)	4
DIETAL-IN (GND)	3
DIETAL-IN (GND)	2
DIETAL-IN (GND)	1
CH636MM CONNECTOR	
GROUND	34
RES232 (K10V HMI)	33
RELAY-BRAKE LAMP	32
RELAY-GEAR PREHEAT	31
SV RETURN	30
CAN+ (1500K)	29
CAN+ (1500K)	28
CAN+ (HIGH/1000K)	27
DIETAL-OUT10	26
DIETAL-OUT9	25
DIETAL-OUT8	24
DIETAL-OUT7	23
DIETAL-OUT6	22
DIETAL-OUT5	21
DIETAL-OUT4	20
DIETAL-OUT3	19
DIETAL-OUT2	18
DIETAL-OUT1	17
DIETAL-OUT0	16
DIETAL-OUT	15
DIETAL-OUT	14
DIETAL-OUT	13
DIETAL-OUT	12
DIETAL-OUT	11
DIETAL-OUT	10
DIETAL-OUT	9
DIETAL-OUT	8
DIETAL-OUT	7
DIETAL-OUT	6
DIETAL-OUT	5
DIETAL-OUT	4
DIETAL-OUT	3
DIETAL-OUT	2
DIETAL-OUT	1

MCU and CLUSTER upgrade connector (FL-CDT)

Kubota service tool connector (DIAGMASTER)



Electric system – electric diagram (power circuit)

1. POWER CIRCUIT

The negative terminal of the battery is grounded to the machine chassis.

When the start switch is in the off position, the current flows from the positive battery terminal.

1) OPERATING FLOW

Battery(+) → Start motor [CN-45 (B+)]

→ Heater relay [CR-24] → Air heater

→ Start relay [CR-23]

→ Fuse box [CN-36 (1)] → I/conn [CS-2 (1)] → Alternator [CN-74 (B+)] → I/conn [CN-2 (2)]

→ Start switch [CS-2 (1)]

→ Fuse box [No.4] → I/conn [CN-2 (4)] → Horn [CN-25 (1)]

→ Fuse box [No.5] → I/conn [CN-2 (9)] → Flasher unit [CR-11 (2) → (1)]

→ Hazard switch [CS-41 (5, 2)]


→ Combi switch [CS-12 (1)]

2) CHECK POINT

Engine	Key switch	Check point	Voltage
OFF	OFF	① - GND (Battery(+)) ② - GND (Fuse No.1) ③ - GND (Fuse No.3) ④ - GND (Start key)	24V

※ GND : Ground

POWER CIRCUIT



Electric system – electric diagram (starting circuit)

2. STARTING CIRCUIT

1) OPERATING FLOW

Battery (+) terminal → Fuse box [CN-36 (1)] → Alternator [CN-74 (B+)] → I/conn [CN-2 (2)]
 → Start switch [CS-2 (1)] → Start motor [CN-45 (B+)] → Start relay [CR-23]

※ The engine can be started only when the gearshift is in neutral position.

(1) When start key switch is in ON position

Start switch ON [CS-2 (2)] → I/conn [CN-2 (1)] → Fuse box [No.36 →33] → ECU (IG)

(2) When start key switch is START position

Start switch START [CS-2 (2)] → I/conn [CN-2 (3)] → Fuse box [No. 34 →31]


→ Neutral relay [CR-5(3) → (4)] → Start relay [CR-23]
 → ECU [CN-91 (12)]

2) CHECK POINT

Engine	Key switch	Check point	Voltage
Running	ON	<ul style="list-style-type: none"> ● - GND (Battery B+) ② - GND (Start key) ③ - GND (Neutral relay) 	24V

※ GND : Ground

STARTING CIRCUIT




Electric system – extra: rear camera as front camera


For this retrofitting we use the ready harness, located in the rear of OHG.
 Part number of the camera to be ordered – **21AB-30041**.
 Installation of camera/bracket and harness must be arranged individually.




Connectors don't match
 Manual modification is necessary




CN-249



CAMERA



CN-249



FORKLIFT



Electric system – Cluster



Electric system – Display



Electric system – Display

For Cluster software higher than v1.5

Auto re-gen active

Park re-gen available

Mast inclination

Speed indicator

Fuel

E/G temperature

Machine F/R inclination

Machine L/R inclination















Weight indicator














ODO meter

Hour meter








Electric system – Display – Warnings 01

S/No.	Warning lamp types	Symbol	Warning and indicator lamp	Causes and correction
1	Engine oil pressure warning		Engine oil pressure warning lamp	Engine oil pressure is low. Please the engine oil refill.
2	Engine warm-up indicator		Engine warm-up indicator lamp	Warm-up will be started.
3	Air cleaner warning		Air cleaner warning lamp	Replace the filter.
4	Water in fuel warning		Water in fuel warning lamp	Please drain the water of water separator.
5	Engine check warning		Engine check warning lamp	Check the failure code of cluster.
6	Engine stop warning		Engine stop warning lamp	Check the failure code of cluster.
7	DPF regeneration warning		DPF regeneration warning lamp	If necessary, display the regeneration DPF.
8	DPF inhibit indicator		DPF inhibit indicator lamp	DPF regeneration status is prohibited.
9	Exhaust high temperature warning		Exhaust system high temperature warning lamp	High temperature state of exhaust system.
10	Fuel warmer indicator		Fuel warmer indicator lamp	warming up the fuel.
11	TM oil temperature warning		TM oil temperature warning lamp	TM oil is over temperature condition.
12	Parking brake indicator lamp		Parking brake indicator lamp	Parking brake is operating.
13	Brake oil level warning		Brake oil level warning lamp	Brake oil level is low. Please the brake oil refill.
14	Battery charging warning		Battery charging warning lamp	Charging the battery is bad. Please check alternator and wiring.

15	Tilt lock indicator		Tilt lock indicator lamp	Auto-leveling is the operational status.
16	OPSS indicator		OPSS indicator lamp	OPSS is working. Blocking driving or operation of the device.
17	Fuel warning		Fuel warning lamp	Fuel level is low. Please the diesel oil refill.
18	Coolant temperature warning		Engine coolant temperature warning lamp	Engine coolant is over temperature condition.
19	T/M oil warning or clutch protection		T/M oil warning lamp	Clutch protection system operating or TM oil level is low. Please the T/M oil refill. *
20	Communication error warning		Communication error warning lamp	Communication with between MCU and ECU is fail condition. Check communication line.
21	Communication error warning		Communication error warning lamp	Communication with between CLUSTER and MCU is fail condition. Check communication line.
22	LH Turn indicator		LH Turning pilot lamp	-
23	RH Turn indicator		RH Turning pilot lamp	-
24	Forward first gear		Forward first gear indicator lamp	-
25	Forward second gear		Forward second gear indicator lamp	-
26	Reverse first gear		Reverse first gear indicator lamp	-
27	Reverse second gear		Reverse second gear indicator lamp	-

Electric system – Display – Warnings 02

28	Expendables		expendables replacement	light up only 3 minutes since KEY ON, and then light off.
29	Engine warm-up		Ignition ON	Start cranking after light off
30	Speed warning indicator		Set speed exceeded	Alarm buzzer will ring every two seconds
31	DPF regeneration		Auto Regeneration Activated	DPF in Lv1 and auto re-gen ongoing
32	DPF regeneration		Parked Regeneration Available	DPF in Lv2, parked regeneration possible

* - Conditions:




When T/M main pressure stays between 0,8~5,7 bar for more than 2 seconds

= warning lamp ON




When accelerator is pressed more than 10 seconds at above T/M main pressure(condition. 1)

= warning lamp ON + buzzer sound

Electric system – Display – Structure – old [soft ~MCU v1.6; CLUSTER v1.5]

No	Main menu	Sub menu	Explanation
1		Model select Vehicle tilt Initialize Weight sensor setup Ignition control setup Camera setup Auto-shift speed setup DCSR speed setup Maximum speed warning MCU Monitor information	Diesel, LPG Vehicle tilt Initialize Enter the cylinder cross section area , Adjust load weight, Weight display setup Ignition control, Change password Interoperate with reverse gear 1st gear-> Switching speed to 2nd gear, 2nd gear -> Switching speed to 1st gear DCSR On, Block driving speed, Restore driving speed Maximum speed warning MCU/Monitor Information
2		Failure History Expendables management I/O Information A/S Contact	Current engine failure, Engine failure history Change oil and filter replacement cycle Analog Input, Digital input/output Change A/S contact
3		LCD Brightness Time Setup Unit Setup Language Setting	Automatic, Manual Clock Speed, Weight, Temperature, Pressure, Date type Korean, English

Electric system – Display – Structure – new [soft MCU v1.6; CLUSTER v1.5~]

Main menu	Sub menu	Explanation	
 <p>Equipment</p>	password	Model select	Diesel, LPG, capacity
		Tilt setup	Calibration of tilt sensors
		Weight sensor setup	Calibration of pressure sensor, lift cylinder cross area
		ESL setup	on/off, delay
		Camera	on/off; settings
		Auto-shift speed setup	on/off; settings
		DCSR speed setup	on/off; settings
		Maximum speed warning	on/off; settings
 <p>Maintenance</p>	password	MCU Monitor information	info
		Engine failure history	info
		Maintenance management	confirmation/interval change
		Signals information	digital/analog; info [5 new analog signals added]
 <p>Display Setting</p>	open	User password change	! service password change ! 00000 → XXXXX !
		LCD Brightness	
		Time Setup	
		Unit Setup	
		Language Settings	
		A/S Contact	
ESL password setup	Password setup/change		
Maintenance management	info		

**ENTERING
PASSWORD FOR
EACH SUB-MENU IS
NOT NECESSARY
ANY MORE**

On some of next slides you can find old configuration

Electric system – Display – Equipment – Model Select

Model select

Device setup > Model select


Please select the fuel type.

Please select the vehicle capacity range.

Please select the exact model name.

* Selection will be cancelled if press the cancel button or ESC

* To use full function of vehicle, exact model must be selected.



Electric system – Display – Equipment – Tilt setup

Tilt setup

The tilt sensor has already been initialized when deliver the vehicle from factory.


Initialize vehicle tilt if the tilt sensor figure or vehicle tilt is not horizontal in the flatland.

Vehicle set up > Initialize vehicle tilt

You must position the machine on flat horizontal surface.

*If tilt sensor for mast is mounted (optional), locates the mast vertically.

*Mast maximum angle depends on the vehicle.



Electric system – Display – Equipment – Weight indicator 01



Weight sensor set up

The weight sensor has already been set when deliver the vehicle from factory.

Device setup > Weight sensor setup

There are 4 steps to activate weight indicator


- 1. A cylinder cross sectional area** value will be displayed in initial screen, please enter the cross sectional area using scroll buttons and ENTER button. Please finish setup using ENTER button when input is done.
- 2. Unload condition.** Wait 3 seconds after lifting no-load fork approximately 30 cm from the ground level, then press OK.



No	Model	Mast Type	Cyl. Cross Section(cm^2)
1	15/18/20D-9	V	31.81
	15/18/20D-9S	VF	44.18
		TF	33.18
		TS	39.27
2	22/25D-9	V	39.27
	22/25D-9T	VF	44.18
	22/25D-9S	TF	44.18
	22/25D-9W	TS	47.52
		QF	88.36
3	30/33D-9	V	47.52
	30/33D-9T	VF	56.75
	30/33D-9S	TF	56.75
	30/33D-9W	TS	56.55
4		QF	88.36
	35/40/45D-9A	V	66.37
	35/40/45D-9S	VF	86.59
		TF	86.59
5		TS	88.36
	50DA-9A	V	76.97
	50D-9SA	VF	86.59
	TF	86.59	
		TS	88.36

Electric system – Display – Equipment – Weight indicator 02

3. Load condition. Please enter load weight.
 Please lift the loaded forks approximately 30 cm from the ground level.
 If set is completed, the screen will be switched automatically.
 Please proceed the operation within 30 seconds.
 Operating will be cancelled automatically if the time is elapsed
 Operating will be cancelled automatically if the time is elapsed.



Electric system – Display – Equipment – Weight indicator 03

4. Initialization.

Initialization

Necessary in case of sensor or MCU exchange to delete old settings



Select ↓



→




↑




→



↓



Electric system – Display – Equipment – ESL



ESL Settings

Device Setup > Ignition control

Password request screen will be displayed if you select the menu.


Password length must be longer than 5 digit and less than 10 digit.

Next step is allowed only if password is authenticated.


Electric system – Display – Equipment – Camera



Select  ↓



 ↑



Reverse gear ↓ ↑



Camera setup

Device setup > Camera setup

After set the reverse gear interoperation as ON, the screen will be changed from main screen to camera mode if put gear into reverse, and if the gear is changed, screen will be back to the main screen.

Electric system – Display – Equipment – Auto-Shift Mode



Auto-shifting mode


Device Setup > Auto-Shift setup

User password is required in order to set this function.

In automatic mode, the gear is switched automatically by vehicle speed.

Enable to set the gear switching speed.

Electric system – Display – Equipment – DCSR




Direction Change Shock Relieve

Device setup > DCSR setup

User password is required in order to set this function.

If the setting is ON, driving will be blocked if the driving speed is over the specified speed.

Driving will be continued if the driving speed is not over the specified speed




Electric system – Display – Equipment – Speed Warning




Select  ↓




 ↑



↓ 



↓ 




Driving speed warning

Device Setup > Driving speed warning

User password is required in order to set this function.

If alarm is set as enable, setting speed will be displayed on the screen, and the buzzer rings every 2 seconds

Electric system – Display – Equipment – Speed Limiter



Driving speed limit

Device Setup > Driving speed Limit

Minimum speed = 8 km/h

Package is available on-line in CERES, Additional Info FK section, IC forklifts

Electric system – Display – Equipment – Speed Limiter

For update you need:

1. Diagmaster tool (KUBOTA) + preinstalled software - refer to Service Bulletins on-line:

• Service bulletin list

Search criteria

Model no.

Subject

Specification

Period from

till

Kind of concern

Part group

HHI Bulletin No

Search **Clear**

Bulletins IR

Go Rows **Actions**

Row text contains "kubota"

Bulletin No	Model no.	Subject	Partgroup	Kind Of Concern
HHIE-SB-2014-044	70D-7A, 35D-9A, 50D-7A, 50DA-9A, 40D-9A, 60D-7A, 45D-9A	2015 Update Kubota Diagnostic Tool (Diagmaster) ID, Password and registration code.	-	-
HHIE-SB-2014-026	70D-7A, 35D-9A, 50D-7A, 50DA-9A, 40D-9A, 60D-7A, 45D-9A	Kubota Diagnostic Tool Installation (Diagmaster). Part No. [XJBT-02547]	-	-











1 - 2 of 2

See also slide no 106

Electric system – Display – Equipment – Speed Limiter

For update you need:

2. FL-CDT tool (CLUSTER and MCU) + preinstalled software - refer to information on-line:

SERVICE				
⊕ A/S Report Entry	Restoring Jig - Timer Gear Puller	Natasja Aerts	30-07-2013	 423 kb
⊕ A/S Report Status	<u>Load indicator set-up - new display</u>	Grzegorz Nowakowski	15-05-2014	 341 kb
⊕ Warranty Claim Status	<u>DST-i Hyundai database</u>	Grzegorz Nowakowski	18-07-2014	 14432 kb
⊕ Service Bulletin	 MCU and CLUSTER software upgrade package	Grzegorz Nowakowski	09-09-2014	 5367 kb
⊕ Product Problem Report	CD DIAGMASTER CONTENT	Grzegorz Nowakowski	16-03-2015	 79187 kb
⊕ Aftersales Technical Info	CD FD Tool content	Grzegorz Nowakowski	14-04-2015	 4259 kb
⊕ Service Manual CE	 35d-50da-9a Speed Limiter package	Grzegorz Nowakowski	17-04-2015	 7302 kb
⊕ Service Manual FK	IMPORTANT REMARK CONCERNING THE BATTERY BOX DIMENSIONS:			
⊕ Operation Manual CE	Please be advised that some drawings are mentioning an incorrect battery connector type.			
⊕ Operation Manual FK	In Europe generally a SBE320 (Bleu) is applied. Some drawings are referring to another kind of connector.			
⊕ Service Parts Handbook				
⊕ Technical Handbook				
⊕ Circuit Manual CE				
⊕ Attachment dimensions (previous models)				
⊕ Attachment dimensions (recent models)				
⊕ Additional Info FK 				
⊕ Kubota weblink FK				

See also slide no 105

Electric system – Display – Equipment – Information



Select  ↓





MCU / Cluster Info.	
MCU	Cluster
21FV-40100	21FV-40110
Manufacturing Date	Manufacturing Date
2013/08/25	2013/04/02
Version Info.	Version Info.
1.0	0.9
Serial No.	Serial No.
13D10-015	13D02-001

MCU / Monitor information

Device Setup > MCU/Monitor information

MCU, manufactured date and version of monitor, and serial number will be displayed

Electric system – Display – Maintenance – Engine error codes




Suspect Parameter Number Failure Mode Identifier


Repair

 KUBOTA V3800-CR-TE4 DM.pdf

 Examples of SPI_FML.pdf



Electric system – Display – Maintenance – Expendables 01



 A screen titled "Maintenance Management" displaying a table of maintenance items. The table has columns for Item, Interval, Elapse Count, and Alarm.

Item	Interval	Elapse Count	Alarm
Axle Planetary Ge...	100	2 0	<input checked="" type="checkbox"/>
Transmission Oil	100	2 0	<input type="checkbox"/>
Transmission Oil F...	100	2 0	<input type="checkbox"/>
Hydraulic Tank Al...	250	2 0	<input type="checkbox"/>
Air Cleaner Comp...	450	2 0	<input type="checkbox"/>
Engine Oil Filter	500	2 0	<input type="checkbox"/>



How to replace expendables

Device setup > Expendables management.
 If the expendables replacement cycle has been passed, alarm will be displayed as ON.
 Press the "Expendables replacement" if replaced the expendables.
 Information about recent replacement (max. 9) will be displayed.
 If you want to change the cycle, please press the "Change cycle" button.

Electric system – Display – Maintenance – Expendables 02



How to replace expendables

Device setup > Expendables management


If the expendables replacement cycle has been passed, alarm will be displayed as ON.

Press the "Expendables replacement" if replaced the expendables.

Information about recent replacement (max. 9) will be displayed.

If you want to change the cycle, please press the "Change cycle" button.

Electric system – Display – Maintenance – Expendables 03



How to replace expendables

Device setup > Expendables management





If the expendables replacement cycle has been passed, alarm will be displayed as ON.

Press the "Expendables replacement" if replaced the expendables.

Information about recent replacement (max. 9) will be displayed.

If you want to change the cycle, please press the "Change cycle" button.

Electric system – Display – Maintenance – Signals



Electric system – Display – Maintenance – Change user password




User password change
Before releasing machine to end-customer please change default password "00000" to your own and record it safely.



Electric system – Display – Display Settings – A/S info




Select  ↓



▽ ↑



Electric system – Display – Display Settings – ESL – Change password



Change password

Display settings > ESL Password change


Change password

This function is to allow to change password from default password to user defined password.

Password length must be longer than 5 digits and less than 10 digits.

If you forget the password, you must request the HHIE, do not forget the password!

Electric system – Display – Display Settings – Maintenance info



Maintenance Information

Display settings > Maintenance management

Information about:

1. Interval between services
2. Elapsed hours from last maintenance
3. Number of services done
4. Alarm active/inactive

Engine





Engine – Specification

Model Name	V3800-CR-TE4B-HHI-1	V3800-CR-TIE4B-HHI-1 (50~70D-7A)
Engine Type	Vertical, water-cooled, 4-cycle DI diesel engine	
Bore x Stroke	100 x 120 mm (x 4 = 3769 cm ³)	
SAE Gross Continuous	61.0 kW (82.9 PS) / 2200 rpm	68.3 kW (92.9 PS) / 2200 rpm
SAE Gross Intermittent	70.2 kW (95.4 PS) / 2200 rpm	78.6 kW (107 PS) / 2200 rpm
Maximum Speed	2550 rpm	2525 rpm
Minimum Idling Speed	875 - 925 rpm	
Direction of Rotation	Counter-clockwise (Viewed from flywheel side)	
Firing Order	1-3-4-2 (1 : Fan side)	
Compression Ratio	17.5	
Oil Pressure Indicating	Electrical Type Switch	
Starter Motor	24 V, 3.2 kW	
Fuel	Ultra Low Sulfur (max 15 p.p.m.)	
Lubricating Oil	CJ-4 (capacity : 13.2L)	
Weight (Dry)	316 kg	
Application	Forklift Truck	

Engine – Specification – Model – Serial number






V	Number of cylinder = Vier 4 cylinder
3800	Total displacement = approx. 3800 cm ³ (3.8 L)
CR	Common Rail system
T	Turbocharged
I	Intercooler (only for 50~70D-7A)
E4	Emission regulation = Tier4



Engine – Electronic control

ECU controls electrical valves position according to sensors' values

Sensor	
1.	<u>Rail Pressure</u>
2.	<u>Fuel Temp</u>
3.	<u>Coolant Temp</u>
4.	<u>Intake Air Temp</u>
5.	<u>Intake Air Pressure</u>
6.	<u>Crank Position (NE)</u>
7.	<u>Cam Position (G)</u>
8.	<u>Barometric Pressure</u>
9.	<u>Air Flow Sensor</u>
10.	<u>Differential Pressure</u>
11.	<u>T0</u>
12.	<u>T1</u>
13.	<u>T2</u>




Engine – Electronic control

Controllable injection timing and multiple injection.


High pressure fuel injection.

High Pressure Fuel System




Supply Pump

compress fuel and send to Rail



Rail



always keep high pressure fuel



Injector

inject fuel into combustion chamber



Engine – Sensors – Rail Pressure



- ▶ **Rail Pressure:** below 160 Mpa.
- ▶ **Pressure Limiter:** emergency open at 200 MPa.
- ▶ Rail Pressure Sensor and Pressure Limiter are **not service parts.** (change with Rail Assembly)

Engine – Sensors – Fuel Temperature Sensor



Fuel Temp. Sensor



- ▶ The sensor is service parts, but **replacing makes warranty expired.**
- ▶ (recommend replace by pump assembly in warranty period.)

Engine – Sensors – Coolant Temperature Sensor



Coolant Temp. Sensor



- ▶ Checking overheat. Overheat is over 120°C.
- ▶ 65°C - start control for emission (ex. EGR valve, Regeneration...)



Engine – Sensors – Intake Air Temperature Sensor

Intake Air Temp. Sensor




Engine – Sensors – Intake Air Pressure Sensor


Intake Air Pressure Sensor




Engine – Sensors – Crankshaft Position Sensor (NE sensor)



NE sensor




Pulsar gear



- ▶ for control **Injection timing**, measures **Engine rpm**


Engine – Sensors – Camshaft Position Sensor (G sensor)



G sensor




Pulsar gear



- ▶ For judging that piston is at Compression Top or Overlap Top

Engine – Sensors – Barometric Pressure Sensor

Vent for Barometric Pressure sensor





ECU






- ▶ ECU base plate has circuit for sensing barometric pressure
- ▶ If broken, change by Assembly

Engine – Sensors – Air flow sensor





- ▶ Checking quantity of fresh air.
- ▶ For better control of EGR function

Engine – Sensors – Differential Pressure Sensor




- ▶ Measures pressure before and after the DPF
- ▶ Used to calculate PM accumulation

Engine – Sensors – Exhaust Gas Temperature Sensor (T0, T1, T2)




► For control of Regeneration process in DPF

Engine – Valves – INJECTOR | Two Way Valve [TWV]





Always High pressure



▶ [Fuel flow] Supply pump → Rail → Injector

Engine – Valves – INJECTOR | Two Way Valve [TWV]

Timing	When the ECU applies the current to the solenoid ?
Quantity	How long the ECU applies the current to the solenoid ?
Number of times	How many times the ECU applies the current to the solenoid ?



Solenoid

Pre

Smooth
explosion

Main

Power

After



burn unburnt
fuel again

Post



Regeneration

- ▶ Injection timing, quantity, and number of times are controlled by electrical solenoid in the injector.
- ▶ Injector is always filled with high pressure fuel.
- ▶ **1500h** maintenance (execute Injection Stop by Diagmaster)




Engine – Valves – Suction Control Valve [SCV]




Valve open



Valve closed



SCV



- ▶ Equipped on Supply Pump and control **fuel quantity flow in Supply Pump**.
- ▶ Valve position is controlled by time length of currency | Duty Control
- ▶ SCV is **service part**. But replacing makes warranty expire (recommend to replace by pump assembly in warranty period).

Engine – Valves – EGR System

EGR Valve


EGR Cooler






Reed Valve

EGR valve position sensor

Coil



Magnet rotor

 Min operating temp - 65°C




- ▶ EGR system is to decrease exhaust gas temp. to reduce Nox, starts from 65°C~
- ▶ Reed valve is to prevent back flow
- ▶ **Ultra Low Sulfur Fuel** required

Engine – Valves – Throttle Valve




- ▶ Increase exhaust gas temperature for Regeneration.
- ▶ Built-in valve position sensor

Engine – Intake Air Heater



- ▶ draws approx. 50 amps per element.
- ▶ controlled by Coolant Temp. Sensor value.

After Treatment Device




After Treatment Device

Trap

Regeneration


Cleaning



Engine

Diesel Oxidation Catalyst
(DOC)

Diesel Particulate Filter
(DPF)




After Treatment System

After Treatment Device

Main Components

- Diesel Particulate Filter [DPF]
- Diesel Oxidation Catalyst [DOC]
- Three Temperature Sensor (T0, T1, T2)
- Differential Pressure Sensor



- ▶ *After Treatment Device* is assembly to clean exhaust gas, especially PM.

After Treatment Device

Trap

Regeneration

Cleaning


EXHAUST GAS

CO ₂	Exhaust Gas Recirculation
H ₂ O	
CO	<u>Tier3 / Stage IIIA</u> Common rail
C _p H _q	
C(soot)	PM <u>Int. Tier4 / Stage IIIB</u>
Metal	Ash After Treatment System
NO _x	<u>Final Tier4 / Stage IV</u>

PM : Particulate Matter

-
-
-
-
-
-
-
-

Diesel Particulate Filter (DPF)



After Treatment Device

Trap

Regeneration


Cleaning

Structure

- honeycomb structure to create more surface area.
- a lot of small holes on the wall.
- made from Silicon Carbide.
- covered with catalyst which react with PM during regeneration.
(Activation Temperature : 550 °C)



Trap PM



▶ *DPF* is a filter to trap PM

After Treatment Device


Trap

Regeneration

Cleaning

Mechanism

Thanks to catalyst on DPF, PM can combine with O_2 in exhaust gas to form CO_2 at $550\text{ }^\circ\text{C}$. CO_2 is so small that get out through holes of DPF wall.



- ▶ **Regeneration** is a process to change PM into CO_2 by chemical reaction (catalytic reaction) in order to restore filtering function without replacement.



After Treatment Device

Trap

Regeneration

Cleaning


ENGINE



Diesel Oxidation Catalyst (DOC)


250°C~

550°C~



DPF

After Treatment Device



After Treatment Device

There are 3 types of Regeneration.

All regeneration have same purpose: removing accumulated PM.

Auto Regeneration

If Auto Re-gen is permitted, ECU starts Re-gen automatically according to PM level.
Application can continue operation.

Parked Regeneration

If PM doesn't burn enough by Auto Re-gen, ECU requires to stop operation and concentrate Parked Re-gen.

Manual Regeneration (with Diagmaster)

Too much PM could generate too much heat when Re-gen and it is dangerous for end user.
Only service staff can regenerate with Diagmaster.

After Treatment Device

50% output

P3008	Lv. 5	Auto	Parked	Manual	Cleaning	36000 - ~
P3007	Lv. 4	Auto	Parked	Manual		31000
P3006	Lv. 3	Auto	Parked			26000
unlimited	Lv. 2	Auto	Parked			21000
30 min	Lv. 1	Auto				
	Lv. 0	No need Regeneration				4000

PM SQ 2


PM sedimentation level

PM quantity is calculated by ECU according to rpm, temperature, fuel quantity, differential pressure

PM Sedimentation Quantity 1: calculated from Differential Pressure.


PM Sedimentation Quantity 2: calculated from many parameters.

After Treatment Device – Auto Regeneration Lv1 and Lv2





Automatic regeneration logic			
Level	Regeneration condition	Regeneration environment	
L1	10 min @ 580° or 20 min @ 500° within 30 min timeframe (but not continuously necessary "accumulated") when succesfully done - system goes to Lv = 0 and sedimentation = 4000 mg	Idle 905 rpm post injection	DPF valve 56 bar (when system pressure reaches 80 bar - DPF valve off by software) seat switch off 1 min → rpm ↑ 1100 rpm seat switch closed - back to 905 rpm
L2	~ the same conditions as in Lv1 but without time frame ~ system checks only sedimentation level as it may not exceed 26000 mg -> to Lv3 when 10 min @ 580° succesfully done - system goes to Lv = 0 and sedimentation = 4000 mg when 20 min @ 500° succesfully done - system goes to Lv = 0 and sedimentation = 11000 mg ~ system tries to reach one of above conditions without exceeding pm level higher than 26000 mg		

After Treatment Device – Parked Regeneration Lv3



- Step 1: Move the vehicle to safe(fireproof) place
- Step 2: Stop and park the machine
- Parking brake – ON
 - Accelerator pedal – 0%
 - F/R switch – N
- Step 3: Wait until coolant reaches 65 °C
- Step 3: Push the parked regeneration switch for 3 seconds




After Treatment Device – extra: Cluster and MCU upgrade


In case of problems with frequent Parked Regeneration, we recommend upgrading software version of Cluster and MCU as in package available on-line in CERES.

ZIP file in CERES contains all necessary manuals to guide you through installation and updating process.

Additional info FK

[bps9901]
[HHIE - Service department]

Trucks	Description	Writer	Date	Evidence
	MCU and CLUSTER software upgrade package	Grzegorz Nowakowski	09-09-2014	 5367 kb



After Treatment Device – Manual Regeneration Lv4

Lv4

To execute regeneration in Lv4 – DIAGMASTER diagnostic tool is necessary [**DST-i Kit p/n: XJBT-02547**]
User cannot start this procedure. Only authorized services have authority to perform this regeneration.
Regeneration in Lv4 is the same Parked Regeneration as Lv3. DIAGMASTER just activates the switch, which in Lv4 is deactivated due to safety reasons.



After Treatment Device – Status Lv5

Lv5

Trap

Regeneration

Cleaning

If system goes to Lv5, cleaning of filter is necessary. Cleaning will done by KUBOTA service network To avoid unnecessary machine down-time filter exchange program

The fact of cleaning or replacing the filter, must be manually registered on KUBOTA website via KiSS system.

Access to KiSS system is possible via CERES



- 13. After Sales Info
- Service Manual CE
- Service Manual FK
- Operating Manual CE
- Operating Manual FK
- Technical Handbook
- Circuit Manual CE
- Service Parts HandBook
- Service Policy
- Bucket Dimensions previous
- Dimensions 9-Series
- Flat Rate Tables
- Document Report Form
- Additional info FK
- Training material CE -3 -7 (A)
- Training material FK
- Training material CE -9(A)
- Training material CE ENGINES
- [Kubota^{NEW}](#)

Kubota
Kubota Engine Integrated Service System **K-ISS**

ECU Service and Diagnosis

- ▶ ECU Data Pack(DPK) Download
- ▶ ECU Trim Data Registration
- ▶ DPF Service Info Registration

Copyright Since 2011 KUBOTA Engine Division All rights reserved.



Engine Serial No.	Engine Model Name	Engine Model Code	DPF Part No.	DPF Serial No.	Hourmeter	Serviced Date
2DY3530	V3800-CR-TE4B-HHI-1	1J43312000	1J50018252	3UKA004B10		

	DPF COMP		DOC COMP		Hourmeter	Serviced Date (YYYY/MM/DD)
	Part No.	Serial No.	Part No.	Serial No.		
Old	1J50018252	3UKA004B10	1J43318151	3UJB097A10		
New						

DST-i Tool - Features

Diagnosis

- Checking DTC
- Checking parameters
- Checking valves

DPF control

- Soot Load Reset
- Regeneration Interval Reset
- Manual Regeneration

Calibration

- Supply Pump Learning
- Injector Compensation
- Injection Timing Correction

**DST-i Kit p/n:
XJBT-02547**



DST-i Tool - Installation

Three files are necessary:

Driver: Setup_DST-iV110.exe [Kubota CD]

Program: SetUp_Diagmaster_Ver333.exe [Kubota CD]

Database: SetUp_Diagmaster_DB_For_Hyundai_Ver3.3.2.exe [CERES]

Details in attached files:




Installation sequence (Read first before starting installation as advised through HHIE-SB-2014-026).pdf



HHIE-SB-2014-026 Kubota Diag Tool inst - Update Dec 2014.pdf

DST-i Tool – Menu Structure

Change of ECU software



Troubleshooting and calibrations

Hardware settings

DST-i Tool – Diagnosis – DTC

Diagmaster

Project

DTC

Data Monitor

Active Test

Utility

FF	DTC	Status	Trouble Details
!	P0016	Past	NE-G phase shift
!	P0087	Past	Pressure limiter emergency open
!	P0088	Past	High rail pressure
!	P0089	Past	SCV stuck
!	P0093	Past	Fuel leak (in high pressured fuel system)
!	P0112	Past	Intake air temperature error: Low
	P0113	Present	Intake air temperature error: High
	P0117	Present	Coolant temperature sensor: Low
	P0118	Present	Coolant temperature sensor: High
	P0182	Present	Fuel temperature sensor: Low

Read DTC

Continuous Read DTC

Read parameters

Save as *.csv

Erase DTC

Save DTC in project



Error code list
- see slide no 58

- ▶ DTC is signals from ECU according to calculation from sensor value or other electrical signals.
- ▶ FF | **Freeze Frame data** is engine status when the DTC occurred.
- ▶ ! means it has FF.

DST-i Tool – Diagnosis – Data Monitor

The screenshot shows the Diagmastrer Data Monitor interface. On the left, a sidebar contains buttons for Project, DTC, Data Monitor (highlighted with a green arrow), Active Test, and Utility. The main area features a table of signals with their current values and units. On the right, four stacked line graphs display the trends for Final Fuel Injection Quantity, Engine Speed, Coolant Temperature, and Differential Pressure 1. At the bottom, a control bar includes playback controls, a time axis selector, a graph count selector, a save as *.csv button, a print button, a signal group selector, and a replay dropdown menu.

Signal	Value	Unit
<input checked="" type="checkbox"/> Final Fuel Injection Quantity	35.63	mm3/s
<input checked="" type="checkbox"/> Engine Speed	1576	/min(rp)
<input checked="" type="checkbox"/> Coolant Temperature	79	°C
<input checked="" type="checkbox"/> Differential Pressure 1	2.92	kPa
<input checked="" type="checkbox"/> Exhaust Gas Temperature 0	226	°C
<input checked="" type="checkbox"/> Exhaust Gas Temperature 1	217	°C
<input checked="" type="checkbox"/> Exhaust Gas Temperature 2	209	°C
<input checked="" type="checkbox"/> PM Sedimentation Quantity 1	6820	mg
<input checked="" type="checkbox"/> PM Sedimentation Quantity 2	20908	mg
<input checked="" type="checkbox"/> Fuel Quantity after Regeneration	22	L
<input checked="" type="checkbox"/> DPF Regeneration Last Active Time	38.80	h
<input checked="" type="checkbox"/> Regeneration Progress	0	%
<input checked="" type="checkbox"/> DPF Auto Regeneration Inhibit SW	ON	
<input checked="" type="checkbox"/> DPF Regeneration Control Level	0	
<input checked="" type="checkbox"/> DPF Regeneration Control Status	0	
<input checked="" type="checkbox"/> DPF Manual Regeneration Force SW	OFF	

All on one graph

Add flag

Add/remove parameters

Parameter settings

Start recording

Adjustable time-line

Play button (hold)

Select time frame

Save as *.csv

Print

Select parameters by group


Reply saved projects

Move cursor to next flag

Number of graphs on 1 display


▶ DTC cannot support all of troubles. Sometimes it is necessary to figure out the cause of troubles from parameters.

DST-i Tool – Diagnosis – Active tests



► For better test results, please choose related parameters

DST-i Tool – DPF Control – Soot Load Reset



When Required ?

After replacing DPF.


- 3000 hour
- P3008 | PM Level = 5
- P3024 | High Frequency of Re-gen



▶ Reset the value of PM which ECU memorize.

▶ At PM Lv.5, DO NOT reset soot load and execute Manual Re-gen. Too much PM generates too much heat.

DST-i Tool – DPF Control – DPF Regeneration Interval Time Reset




When Required ?

After replacing DPF because of P3024.

- P3024 | High Frequency of Re-gen

- ▶ Bring *Interval Time* back to zero.
- ▶ *Interval Time* is time length since the last Regeneration which ECU counts.
- ▶ Too short interval time cause **P3024**

DST-i Tool – DPF Control – DPF Manual Regeneration Request Function




When Required ?

After replacing DPF, or After replacing ECU or PM Lv.4

- P3007 | PM accumulation Lv.4
- after Cleaning because of P3008
- after Cleaning because of P3024
- When ECU changed

- ▶ Order ECU to send regeneration request signal forcibly.
To execute Regeneration, need to push Re-gen button of application (depends on application)
- ▶ After Manual Re-gen, check 2 parameter at Data monitor.
 - (1). "**DPF Regeneration Control Level**" shows "Level 0"
 - (2). "**DPF Regeneration Control Status**" shows "Level 0"
- ▶ 3 Preconditions | Parking Brake ON , Neutral SW ON, Idling Speed.

DST-i Tool – Calibration – Supply Pump Learning



When Required ?

Supply pump recognized by ECU is different from equipped supply pump.

- When Supply Pump changed
- When SCV changed
- When ECU changed




	SCV Current (Duty Time)	Rail Pressure (Idling)
Standard	1.0 [A]	35 MPa
Old pump	1.0 ± 0.1 [A]	35 MPa
Replaced Pump	$1.0 - 0.2$ [A]	35 MPa

※Value is reference

- ▶ In order to adjust individual difference of every pumps, input the correction current value of SCV. (Fuel quantity is controlled by SCV position.)


DST-i Tool – Calibration – Injector Compensation



When Required ?

Injector of each cylinder recognized by ECU is different from equipped Injector.

- When Injector changed
- When Injector swapped with other cylinder
- When ECU changed




- ▶ In order to correct for variations of injection quantity caused by individual difference of Injectors, input ID code of equipped Injectors into ECU
- ▶ **ID code** is for Diagmaster. (printed by DENSO)
- ▶ **QR code** is for manufacturing line. (we don't use)

DST-i Tool – Calibration – Injection Timing Correction 01

Mechanical T.D.C



Electrical T.D.C




When Required ?

When position relation of NE sensor and pulsar gear change.

- When pulsar gear changed
- When crankshaft changed
- When gear case changed
- When ECU changed






For details, please refer to Kubota Service Manual



- ▶ Match Mechanical T.D.C and Electrical T.D.C (at #4 cylinder) in order to correct injection timing
- ▶ (#17) Mechanical T.D.C is when #4 cylinder's piston comes top.
- ▶ (#18) Electrical T.D.C is when NE sensor detects 14th teeth (0V > 5V).

Injection timing depends on Electrical T.D.C (NE sensor value)

DST-i Tool – Calibration – Injection Timing Correction 02



- ▶ Convert #19[mm] ✗ to [degree] when input crank angle. (F/W Diameter = 385 mm \Rightarrow 1 mm = 0.298 CA)
- ▶ Electrical T.D.C is to the RIGHT (comes AFTER Mechanical) \Rightarrow POSITIVE
- ▶ Electrical T.D.C is to the LEFT (comes BEFORE Mechanical) \Rightarrow NEGATIVE

DST-i Tool – Calibration – Website Registration

13. After Sales Info

- ➔ Service Manual CE
- ➔ Service Manual FK
- ➔ Operating Manual CE
- ➔ Operating Manual FK
- ➔ Technical Handbook
- ➔ Circuit Manual CE
- ➔ Service Parts HandBook
- ➔ Service Policy
- ➔ Bucket Dimensions previous
- ➔ Dimensions 9-Series
- ➔ Flat Rate Tables
- ➔ Document Report Form
- ➔ Additional info FK
- ➔ Training material CE -3 -7 (A)
- ➔ Training material FK
- ➔ Training material CE -9(A)
- ➔ Training material CE ENGINES
- ➔ [Kubota^{NEW}](#)

Kubota Engine Integrated Service System **K-ISS**

ECU Service and Diagnosis

- ▶ ECU Data Pack(DPK) Download
- ▶ [ECU Trim Data Registration](#) ←
- ▶ DPF Service Info Registration

Copyright Since 2011 KUBOTA Engine Division All rights reserved.

ECU Service and Diagnosis

ECU Trim Data Registration (Injector, Injection Timing)

Engine Serial No.	Engine Model Name
2DY3530	V3800-CR-TE4B-HH1-1

Injector Compensation

Original

Cylinder No.1	Cylinder No.2	Cylinder No.3	Cylinder No.4
6FCB AB00	6FDE CAF4	6FAC AD00	6FCB B4F4
C205 EA00	CF00 D900	B0F3 C800	B800 CD00
0000 0000	0000 0000	0000 0000	0000 0000
0000 22	0000 99	0000 E5	0000 91

Cylinder Number



New

Cylinder No.1	Cylinder No.2	Cylinder No.3	Cylinder No.4
____	____	____	____
____	____	____	____
____	____	____	____
____	____	____	____

Injection Timing Correction


Original

0.2

New

- ▶ **New Injectors and Injection Timing have to be registered at KISS.**
- ▶ Ceres -> After Sales Info -> Kubota

DST-i Tool – ECU EXCHANGE



After replacing ECU...

Reset DPF data or calibration required, because new ECU doesn't know your engine well.

- Supply Pump Learning
- DPF Manual Regeneration
- Check ECU Trim data is correct

- ▶ New ECU have to be written many information. Only Kubota can write them. When ECU requires changing, please contact HHIE with Engine S/N.
- ▶ ***If Injector Compensation and Injection Timing Correction registered at KISS***, KBT send new ECU with those data. (you do not need to input them.)
- ▶ New ECU doesn't know the real DPF status such as PM Level, it could cause wrong control.
Manual Re-gen conform actual PM Lv to ECU's PM Lv.

DST-i Tool – ECU Software Upgrade

13. After Sales Info

- ➔ Service Manual CE
- ➔ Service Manual FK
- ➔ Operating Manual CE
- ➔ Operating Manual FK
- ➔ Technical Handbook
- ➔ Circuit Manual CE
- ➔ Service Parts HandBook
- ➔ Service Policy
- ➔ Bucket Dimensions previous
- ➔ Dimensions 9-Series
- ➔ Flat Rate Tables
- ➔ Document Report Form
- ➔ Additional info FK
- ➔ Training material CE -3 -7 (A)
- ➔ Training material FK
- ➔ Training material CE -9(A)
- ➔ Training material CE ENGINES
- ➔ [KubotaNEW](#)

Kubota
Kubota Engine Integrated Service System **KiSS**

ECU Service and Diagnosis

- ▶ [ECU Data Pack\(DPK\) Download](#) ←
- ▶ ECU Trim Data Registration
- ▶ DPF Service Info Registration

Copyright Since 2011 KUBOTA Engine Division All rights reserved.

ECU Service and Diagnosis

ECU Data Pack (DPK) Download








▶ Type2 DPK (PGM+Trim)

▶ Type1 DPK (PGM)

- ▶ **New ECU software can be downloaded from KiSS.**
- ▶ Ceres -> After Sales Info -> Kubota

DPF- exchange: Set the pictures into the right order!


In case of an error code: P3008 (Level 5) or P3024 (Ash) you need to change the DPF filter



This is the right way to do it!!!

Analog Signal

Item	Measurement Value
DPF Level	Lvl 5
Sedimentation Level Q2	21000 mg
Differential Pressure 1	0.8 kPa
Error code P3008 or P3024	
Exhaust Gas Temperature 2	119



DPF Soot Load Reset

Description: The reset DPF ALL Multiplication Value and Status, press the Reset button.

Date Display

DPF Multiplication Quantity (%)	Unit	Unit
100	100	100
100	100	100



DPF Regeneration Interval Time Reset

Description: Press the Regeneration button to start the DPF regeneration process. Press the Regeneration button to start the DPF regeneration process.



DPF filter manual regeneration request in Kubota Diagnostics



Replacement Record Sheet

Barcode and registration details.



DPF filter registration procedure - online

Kubota ECU Service and Diagnostics

- ECU Data (P3008/P3024) Download
- ECU Time Data Registration
- DPF Service Info Registration



DONE!

Fuel Pump Learning End Time Reset

Description: Press the Learning End button to reset the fuel pump learning end time.


Injector Compensation

Injector	Compensation
1	0.0
2	0.0
3	0.0
4	0.0

Maintenance



Maintenance – Lubrication Chart



- NOTES
- ① △: Check, add oil when needed.
 - ② ○ : Change oil or add oil.
 - ③ Figures in squares indicate number of lubricating points.
 - ④ All service intervals in the chart are based on daily, 2 weeks, 1 month, 3 months, 6 months, and service meter readings.


Mark	Kind of lubricants	In moderate weather	Cold region
EO	Engine oil	API CJ-4 class or better	
MO	T/M oil	ATF DEXRON III	
GO	Gear oil	MOBILFLUID 424 + Shell Donax TD (10W30)	
HO	Hydraulic oil	ISO VG 46, VG 68	ISO VG 15
BF	Brake fluid	AZOLLA ZS32 (Hydraulic oil ISO VG32)	
G	Grease	NLGI No. 2	NLGI No.1

New machine uses following fuel, coolant and lubricant.

Description	Specification
Engine oil	SAE 15W-40 (API CJ-4 class)
T/M oil	ATF DEXRON III
Gear oil	MOBIL FLUID 424 + Shell Donax TD (10W30)
Hydraulic oil	ISO VG46/VG68, Hyundai genuine long life hydraulic oil ISO VG15, Conventional hydraulic oil★1
Brake oil	AZOLLA ZS32 (Hydraulic oil ISO VG32)
Grease	Lithium base grease NLGI No.2
Fuel	ASTM D975-No.2 ★2 Ultra low sulfur diesel
Coolant	Mixture of 50% ethylene glycol base antifreeze and 50% water

- SAE : Society of Automotive Engineers
 - API : American petroleum Institute
 - ISO : International Organization for Standardization
 - NLGI : National Lubricating Grease Institute
 - ASTM : American Society of Testing and Material
- ★1 : Cold region
Russia, CIS, Mongolia
 - ★2 Ultra low sulfur diesel
- sulfur content < 15 ppm

Maintenance – Intervals

Service interval	Item No.	Description	Service Action	Oil symbol	Capacity (l)	Service point No.
 35~50D-9A SM (35~50D-9A SM.pdf)	1	Tilt pin & Mast roller	Check, Add	G	-	2
	2	Lift chain	Check, Add	EO	-	2
	4	Brake oil	Check, Add	BF	0.5	1
	5	Parking brake operation	Check, Adjust	-	-	1
	6	Hydraulic oil level	Check, Add	HO	66	1
	8	Engine oil level	Check, Add	EO	13.2	1
	10	Hyd. tank air breather element	Check, Clean	-	-	1
	15	Pedal linkage operation	Check, Adjust	-	-	1
	16	Drive rim & Tire air pressure	Check, Add	-	-	2
	19	Lamp operation	Check, Replace	-	-	9
	21	Fuel level	Check, Add	DF	100	1
	22	Water separator	Check, Drain	-	-	1
	24	Radiator coolant	Check, Add	C	21.5	1
	25	Steer rim & Tire air pressure	Check, Add	-	-	2
10 Hours or daily	26	Fan belt tension	Check, Adjust	-	-	1
	27	Horn operation	Check, Replace	-	-	1
	11	Air cleaner element	Check, Clean	-	-	1
	12	Hydraulic pump drive	Check, Add	G	-	1
50 Hours or weekly	13	Steering axle linkage	Check, Add	G	-	1
	17	Transmission oil level	Check, Add	MO	12	1
	8	Engine oil	Change	EO	13.2	1
Initial 50 Hours	9	Engine oil filter	Replace	-	-	1
	14	Differential gear oil	Change	GO	10.5	1
Initial 100 Hours	17	Transmission oil	Change	MO	12	1
	18	Transmission oil filter	Replace	-	-	1


 35~50D-9A OM (35~50D-9A OM.pdf)

Maintenance – Intervals

250 Hours or monthly	1	Tilt pin & Mast roller	Check, Lubricate	G	-	2
	2	Lift chain	Check, Lubricate	EO	-	2
	10	Hyd. tank air breather element	Replace	-	-	1
	14	Differential gear oil	Check, Add	GO	10.5	1
	28	Fork condition and wear	Check, Replace	-	-	2
500 Hours or 3 monthly	3	Trunnion bolt	Check, Adjust	-	-	4
	8	Engine oil	Change	EO	13.2	1
	9	Engine oil filter	Replace	-	-	1
	11	Air cleaner element	Replace	-	-	1
	20	Fuel filter	Replace	-	-	1
	23	Battery electrolyte	Check, Add	-	-	1 (2)
1000 Hours or 6 monthly	4	Brake oil	Change	BF	0.5	1
	7	Hydraulic oil return filter	Replace	-	-	1
	14	Differential gear oil	Change	GO	10.5	1
	16	Brake condition and wear	Check, Replace	-	-	2
	17	Transmission oil	Change	MO	12	1
	18	Transmission oil filter	Replace	-	-	1
	29	Steering axle wheel bearing	Check, Add	G	-	2
1500 Hours	30	PCV valve	Check, Replace	-	-	1
	31	Oil separator element	Replace	-	-	1
	32	EGR cooler	Check, Replace	-	-	1
2000 Hours	6	Hydraulic strainer	Check, Clean	HO	-	1
	6	Hydraulic oil*1	Change	HO	66	1
	24	Radiator coolant	Change	C	21.5	1
3000 Hours	30	DPF muffler	Clean	-	-	1
5000 Hours	6	Hydraulic oil*2	Change	HO	66	1

Maintenance – Recommended Lubricants

Service point	Kind of fluid	Capacity ^l (U.S. gal)	Ambient temperature° C (° F)						
			-50 (-58)	-30 (-22)	-20 (-4)	-10 (14)	0 (32)	10 (50)	20 (68)
Engine oil pan	Engine oil	13.2 (3.49)	★SAE 5W-40						
			SAE 30						
			SAE 10W						
			SAE 10W-30						
			SAE 15W-40						
Torque converter transmission	Transmission oil	12 (3.2)	ATF DEXRON III						
Axle	Gear oil	10.5 (2.8)	MOBIL FLUID 424						
			+ Shell Donax TD (10W30)						
Hydraulic tank	Hydraulic oil	66 (17.4)	★ISO VG 15						
			ISO VG 46						
			ISO VG 68						
Fuel tank	Diesel fuel★ ¹	100 (26.4)	★ASTM D975 NO.1						
			ASTM D975 NO.2						
Fitting (Grease nipple)	Grease	-	★NLGI NO.1						
			NLGI NO.2						
Brake reservoir tank	Brake oil	-	★AZOLLA ZS10 (Hydraulic oil, ISO VG10)						
			AZOLLA ZS32 (Hydraulic oil, ISO VG32)						
Radiator	Antifreeze : Water	21.5 (5.7)	Ethylene glycol base permanent type (50:50)						
			★Ethylene glycol base permanent type (60 : 40)						

NOTES

- Engine oil should be API classification CJ-4.
- Change the type of engine oil according to the ambient temperature.
When using oil of different brands from the previous one, be sure to drain all the previous oil before adding the new engine oil.
- On DPF-equipped engines, part of the fuel may get mixed with engine oil during the regenerating process. This may dilute the oil and increase its quantity. If the oil rises above the oil level gauge upper limit, it means the oil has been diluted too much, resulting in a trouble. In such case, immediately change the oil for new one.
- If the interval of DPF regeneration becomes 5 hours or less, be sure to change the oil for new one.

★¹Ultra low sulphur diesel – sulphur content < 15 ppm

★ Cold region Russia, CIS, Mongolia

Q & A

